


Simply the best practice.


WORK PROPERLY. INCREASE PROCESS RELIABILITY.

Better Spraying


SET YOUR SPRAY GUN



MOVE HORIZONTAL



APPLY REGULARLY



COMMON MISTAKES AND SOLUTIONS




Spray 90° to substrate



Reduce distance



Reduce spray pattern



Reduce air pressure

SOLUTIONS

